Live Sawn White Oak Engineered Flooring General Specifications

Use: Commercial and Residential flooring installations

Recommended Installation: Glue, Float, Nail, or Staple - See UE Engineered Installation Recommendations for more information.

Engineered Construction:

Wear Layer: Solid White Oak. All wear layers are live sawn cut.

Wear Layer Thickness Options: 4mm (can refinish 3+ times) or 6mm (can refinish 4+ times)

Core: Quarter Sawn Pine with PVA bond

Dimensions:

Thickness Options: 5/8", 3/4" Width Options: 5", 7.5", 10.5"

Lengths: 2'-8' random

Custom thickness and width available upon request

Profile: Tongue and groove with micro bevel

Species: Live Sawn White Oak

Wood may be sourced from the following:

- Select Harvest: Habitat Restoration Projects and Responsibly Harvested Forests
- Urban Wood: Salvaged due to Damage, Disease, Natural Decline, or Development
- FSC® Certified: FSC License Code (FSC-C199866)

Grain and Allowances:

- Natural color variation will occur across floorboards.
- Character Grade: Allows sound and filled knots, mineral streaks, and quartersawn marks.

•

Finish:

Matte Clear

• UV Cured Aluminum Oxide Topcoat

Custom Finishes Available on Request

Resistances: Scratch, Stain, Water, Fade, UV, Warp, Slip

URBAN EVOLUTIONS LIVE SAWN WHITE OAK ENGINEERED FLOORING 2025

Sustainability Attributes:

Sourcing & Ecosystem Health:

- Standard wood sourced from salvaged and responsibly harvested trees
- FSC® Certified Wood Available on Request

Human Health:

- Intertek Certified Clean Air Gold CDPH v1.2 compliant
- No added urea-formaldehyde resins

Climate Health:

- Sourced and manufactured in Wisconsin
- Final assembly in Weston, WI

Circularity:

• Flooring may be refinished at least three times depending on wear layer thickness

LEED:

IEQc4: VOC Emissions Evaluation: Intertek Clean Air Certifications/CDPH v1.2 Compliant

MRc4: Wood Products: FSC® License Code (FSC-C199866)

Warranty: 10 Year Commercial Limited Warranty

Limited Lifetime Residential Warranty

Care & Maintenance: The recommended method for cleaning Urban Evolutions Live Sawn Engineered Flooring is with a damp mop and water. Make sure the moisture content is limited to an amount that will evaporate immediately. See UE Engineered Installation Recommendations for more information.